


# B baby™

## Whirly Pop™

6 MONTHS TO 2 YEARS

Bonk 'em and bop 'em  
and watch 'em pop



**A** Push down to see the balls pop and bop with lights and sounds.

**B** Spin as fast as you can, and watch the beads go bonkers.

**C** Press any of these buttons to hear nursery songs played by different instruments. Hear the guitar, the piano, the flute or even all three at the same time.



Whirly Pop™

6 MONTHS TO 2 YEARS

Bonk 'em and bop 'em  
and watch 'em pop

## REPLACING BATTERIES


### 3 AA (1.5V) BATTERIES INCLUDED

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not throw this product or its batteries in a fire as batteries may explode or leak.
- Dead batteries? Check out [earth911.com](http://earth911.com) to quickly find the recycling center nearest you.

Take a little detour and whirl  
your way to our website at  
[mytoys.com](http://mytoys.com). Questions or comments?  
Call us (toll-free) at 1-866-665-5524

**ATTENTION:** Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



suction cup

© 2016 Maison Joseph Battat Ltd.  
Baby B. and Whirly Pop and  
Just B, Just You. B. You  
are trademarks of  
Maison Joseph Battat Ltd.

Manufactured for  
Maison Joseph Battat Ltd.  
8440 Darnley Road,  
Montreal, P.Q. H4T 1M4  
Designed by  
Maison Joseph Battat Ltd.  
Consumer Information Line:  
1-866-665-5524

100% RECYCLED  
WOOD-FREE PAPER  
PRINTED WITH  
SOY-BASED INKS



BX1464